



**EN**

**Electronic controller with 1 intervention point**

## USER INTERFACE



## ICPlus 902

### KEYS



#### UP

##### Press and release

Scroll menu items  
Increases values

##### Press for at least 5 sec

Function can be configured by the user (H31)



#### STAND-BY (ESC)

##### Press and release

Returns to the previous menu level  
Confirms parameter value

##### Press for at least 5 sec

Function can be configured by the user (H33)



#### DOWN

##### Press and release

Scroll menu items  
Decrease values

##### Press for at least 5 sec

Function can be configured by the user (H32)



#### SET (ENTER)

##### Press and release

Displays alarms (if active)  
Opens Machine Status menu  
Confirm commands

##### Press for at least 5 sec

Opens Programming menu

## ICONS



### Decimal Point

Permanently on: decimal point  
Off: otherwise



### Temperature

Permanently on: displays a temperature  
Flashing: reduced set active, displays a temperature or no unit of measure selected



### Pressure

Permanently on: displays a pressure  
Flashing: reduced set active and displays a pressure



### Humidity

Permanently on: displays a humidity  
Flashing: reduced set active and displays a humidity



### Relay OUT1

Permanently on: OUT1 output active  
Flashing: a delay, a protection or a locked start-up  
Off: otherwise



### Not Used



### Alarm

Permanently on: alarm active  
Flashing: alarm acknowledged  
Off: otherwise

### NOTE:

When switched on, the device performs a Lamp Test; the display and LEDs will flash for several seconds to check that they all function correctly.

## ELECTRICAL CONNECTIONS



### HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Replace and secure all covers, accessories, hardware, cables and wires.
- For all the devices where this is provided, confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this device and any associated products.

**Failure to follow these instructions will result in death or serious injury.**

This device has been designed to operate outside of any hazardous location.  
Only install this device in zones known to be free of hazardous atmosphere.



### POTENTIAL FOR EXPLOSION

Install and use this equipment in non-hazardous locations only.

**Failure to follow these instructions will result in death or serious injury.**

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel.  
No responsibility is assumed by Eliwell for any consequences arising out of the use of this material.

## **WARNING**

### **UNINTENDED EQUIPMENT OPERATION**

- Use appropriate safety interlocks where personnel and/or equipment hazards exist.
- Install and operate this equipment in an enclosure appropriately rated for its intended environment.
- Power line and output circuits must be wired and fused in compliance with local and national regulatory requirements for the rated current and voltage of the particular equipment.
- Do not use this equipment in safety-critical machine functions.
- Do not disassemble, repair, or modify this equipment..
- Do not mount devices in extremely damp and/or dirt-laden areas.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**



Do not exceed the maximum permissible current; in case of higher loads, use a suitably rated contactor.

NTC/PTC/PT100 probes have no connection polarity and can be extended using a normal bipolar cable (Note that extending the probes burdens the behaviour of the instrument in terms of EMC electromagnetic compatibility: specifically, if PT100 probes with cable longer than 3 mt (118 in.) are used, an extreme care must be taken during wiring operations).

Probe cables, power supply cables and the TTL serial cable should be routed separately from power cables.

## NTC/PTC MODEL

### CONNECTIONS



### INPUT/OUTPUT CHARACTERISTICS



Display range:	<b>NTC:</b> -50...110 °C (-58...230 °F) <b>PTC:</b> -50...140 °C (-58...302 °F) on display with 3½ digits + sign
Analogue input	1 <b>NTC</b> or 1 <b>PTC</b> (selectable by parameter <b>H00</b> )
Serial	TTL for connection to Copy Card or Televiis/Modbus remote control systems
Digital output (OUT1)	<b>EN60730</b> - 1 relay SPDT 8(4) A - 250 Vac <b>UL60730</b> - NO: 8 A 240 Vac G.P. ½ HP 240 V NC: 8 A 240 Vac G.P. ½ HP 240 V
Buzzer output	only on models where this is provided
Measurement range	-50...140 °C (-58...284 °F)
Accuracy	better than 0.5 % of end of scale +1 digit
Resolution	0.1 °C (0.1 °F up to +199.9 °F; 1 °F over)

### TERMINALS

<b>1-2</b>	NC regulator relay <b>OUT1</b>	<b>*4-5</b>	Power supply 24 Vac, 115 Vac and 230 Vac
<b>1-3</b>	NO regulator relay <b>OUT1</b>	<b>*8-9</b>	Power supply 12 Vac/dc and 12-24 Vac/12-36 Vdc
<b>10-11</b>	Probe Pb1 Input		
<b>A</b>	TTL input	<b>* depends on model</b>	

## NTC/PTC MODEL (with 15 A relay)

### CONNECTIONS



### INPUT/OUTPUT CHARACTERISTICS

Display range:	<b>NTC</b> : -50...110 °C (-58...230 °F) <b>PTC</b> : -50...140 °C (-58...302 °F) on display with 3½ digits + sign
Analogue input	1 <b>NTC</b> or 1 <b>PTC</b> (selectable by parameter <b>H00</b> )
Serial	TTL for connection to Copy Card or Televi/Modbus remote control systems
Digital output (OUT1)	<b>EN60730</b> - 1 relay SPDT 15 A - 250 Vac <b>UL60730</b> - NO: 12.5 A 240 Vac resistive 1 HP 240 V NC: 12.5 A 240 Vac resistive ¾ HP 240 V
Buzzer output	only on models where this is provided
Measurement range	-50...140 °C (-58...284 °F)
Accuracy	better than 0.5 % of end of scale + 1 digit
Resolution	0.1 °C (0.1 °F up to +199.9 °F; 1 °F over)


### TERMINALS

<b>1-2</b>	NC regulator relay <b>OUT1</b>	<b>*4-5</b>	Power supply 24 Vac and 230 Vac
<b>1-3</b>	NO regulator relay <b>OUT1</b>	<b>*8-9</b>	Power supply 12 Vac/dc
<b>10-11</b>	Probe Pb1 Input		
<b>A</b>	TTL input	<b>* depends on model</b>	


## NTC/PTC MODEL (with 2 HP relay)

### CONNECTIONS

**NTC/PTC - 2 Hp (12 Vac/dc)**



**NTC/PTC - 2 Hp (230 Vac)**



### INPUT/OUTPUT CHARACTERISTICS

Display range:	<b>NTC:</b> -50...110 °C (-58...230 °F) <b>PTC:</b> -50...140 °C (-58...302 °F) on display with 3½ digits + sign
Analogue input	<b>1 NTC</b> or <b>1 PTC</b> (selectable by parameter <b>H00</b> )
Serial	TTL for connection to Copy Card or Televis/Modbus remote control systems
Digital output (OUT1)	<b>EN60730</b> - 1 relay SPST 16(8)A 2 HP - 250 Vac
Buzzer output	only on models where this is provided
Measurement range	-50 ... 140 °C (-58 ... 284 °F)
Accuracy	better than 0.5 % of end of scale +1 digit
Resolution	0.1 °C (0.1 °F up to +199.9 °F; 1 °F over)

### TERMINALS


<b>4-5</b>	NO regulator relay <b>OUT1</b>	<b>*6-7</b>	Power supply 230 Vac
<b>9-11</b>	Probe Pb1 Input	<b>*7-8</b>	Power supply 12 Vac/dc
<b>A</b>	TTL input	<b>* depends on model</b>	




## V/I MODEL

### CONNECTIONS

V/I (12 Vac/dc, 12-24 Vac/12-36 Vdc)



V/I (24 Vac, 115 Vac, 230 Vac)



### INPUT/OUTPUT CHARACTERISTICS



Display range:	-199...199 (ndt = <b>n</b> ) -199.9...199.9 (ndt = <b>y</b> ) -1999...1999 (ndt = <b>int</b> ) on display with 3½ digits + sign
Analogue input	1 <b>V/I</b> (0-1 V, 0-5 V, 0-10 V, 0...20 mA, 4...20 mA) (selectable by parameter <b>H00</b> ) Maximum load: - current = 100 ohm - voltage = 20 kohm
Serial	TTL for connection to Copy Card or Televis/Modbus remote control systems
Digital output (OUT1)	<b>EN60730</b> - 1 relay SPDT 8(4) A - 250 Vac <b>UL60730</b> - NO: 8 A 240 Vac G.P. ½ HP 240 V NC: 8 A 240 Vac G.P. ½ HP 240 V
Buzzer output	only on models where this is provided
Measurement range	-1999 ... 1999
Accuracy	better than 0.5 % of end of scale + 1 digit
Resolution	1 or 0.1 digit according to settings

### TERMINALS

<b>1-2</b>	NO regulator relay <b>OUT1</b>	<b>*7-8</b>	Power supply 12 Vac/dc and 12-24 Vac/12-36 Vdc
<b>1-3</b>	NC regulator relay <b>OUT1</b>	<b>*9-10-12</b>	Voltage input ( <b>9</b> =GND; <b>10</b> ="+"; <b>12</b> =12 V)
<b>*6-7</b>	Power supply 24 Vac, 115 Vac and 230 Vac	<b>*9-11-12</b>	Current input ( <b>9</b> =GND; <b>11</b> ="+"; <b>12</b> =12 V)
<b>A</b>	TTL input	<b>* depends on model</b>	

# PT100/Tcj-Tck MODEL

## CONNECTIONS



## INPUT/OUTPUT CHARACTERISTICS

Display range:	<b>PT100</b> : -150...650 °C (-238...1202 °F) <b>TcJ</b> : -40...750 °C (-40...1382 °F) <b>TcK</b> : -40...1350 °C (-40...2462 °F) on display with 3½ digits + sign
Analogue input	1 <b>PT100</b> or 1 <b>TcJ / Tck</b> (selectable by parameter <b>H00</b> )
Serial	TTL for connection to Copy Card or Televiz/Modbus remote control systems
Digital output (OUT1)	<b>EN60730</b> - 1 relay SPDT 8(4) A - 250 Vac <b>UL60730</b> - NO: 8 A 240 Vac G.P. ½ HP, 240 V NC: 8 A 240 Vac G.P. ½ HP, 240 V
Buzzer output	only on models where this is provided
Measurement range	-150 ... 1350 °C (-238 ... 2462 °F)
Accuracy	see 'Pt100/TcJ/TcK models' table
Resolution	see 'Pt100/TcJ/TcK models' table

## TERMINALS

<b>1-2</b>	NO regulator relay <b>OUT1</b>	<b>*6-7</b>	Power supply 12 Vac/dc and 12-24 Vac/12-36 Vdc
<b>1-3</b>	NC regulator relay <b>OUT1</b>	<b>*10-11-12</b>	Probe <b>PT100</b> input - 3 wires (Pb1)
<b>*5-6</b>	Power supply 24 Vac, 115 Vac and 230 Vac	<b>*11-12</b>	<b>TcJ/TcK</b> input
<b>A</b>	TTL input	<b>* depends on model</b>	



## PT100/Tcj-Tck MODELS

<b>PT100:</b>	ACCURACY:	0.5 % for whole scale + 1 digit 0.2 % from -150 °C to 300 °C
	RESOLUTION:	0.1 °C (0.1 °F) from -199.9 °C up to 199.9 °C; 1 °C (1 °F) beyond
<b>Tcj:</b>	ACCURACY:	0.4 % for whole scale + 1 digit
	RESOLUTION:	0.1 °C (0.1 °F) from -199.9 °C up to 199.9 °C; 1 °C (1 °F) beyond
<b>Tck:</b>	ACCURACY:	0.5 % for whole scale + 1 digit 0.3 % from -40 °C to 800 °C
	RESOLUTION:	0.1 °C (0,1 °F) from -199.9 °C up to 199.9 °C; 1 °C (1 °F) beyond

## MOUNTING - DIMENSIONS


The device is designed for panel mounting. Drill a 71x29 mm (2.80x1.14 in.) hole and insert the instrument; secure it with the special brackets provided. Do not install the instrument in damp and/or dirty places; in fact, it is suitable for use in places with ordinary or normal levels of pollution.

Keep the area around the instrument cooling slots adequately ventilated.




## EWPA-EWHS PROBE CONFIGURATION


### ● EWHS 284 2 wires




### ● EWHS 304/314 3 wires







### ● EWPA 007/030 2 wires / Transducer




### ● EWHS 314 4 wires (V-I model)



## USING THE COPY CARD/UNICARD

The Copy Card/Unicard is connected to the serial port (TTL) and allows rapid programming of the instrument parameters. Access **Installer** parameters by entering 'PA2', scroll through the folders using  and  until folder **FPr** appears. Select it using , scroll through the parameters using  and , then select the function using  (eg. **UL**).

- **Upload (UL):** Select UL and press . This function uploads the programming parameters from the instrument to the card. If the procedure is a success, 'y', will appear on the display, otherwise 'n' will appear.
- **Format (Fr):** This command is used to format the copy card/unicard (recommended when using the card for the first time).  
**NOTE:** the **Fr** parameter deletes all data present. This operation cannot be cancelled.
- **Download:** Connect the Copy Card/Unicard when the instrument is switched off. At power-on, data is downloaded from the Copy Card/Unicard to the instrument automatically. At the end of the lamp test, the display will show '**dLy**' if the operation was successful and '**dLn**' if not.

**NOTE:** After downloading, the instrument works with the settings of the new map just downloaded.

## ACCESSING AND USING THE MENUS

The resources are organized into 2 menus which are accessed as follows:

- 'Machine Status' menu: press and release the **SET** key.
- 'Programming' menu: hold down the **SET** key for 5 seconds.

Either do not press any keys for 15 seconds (timeout) or press the **ⓘ** key once, to confirm the last value displayed and return to the previous screen.

## PASSWORD

**Password 'PA1'**: used to access **User** parameters. The password is not enabled by default (**PS1=0**).

To enable it (**PS1≠0**): press and hold **SET** for longer than 5 seconds, scroll through the parameters using **⏪** and **⏩** until you see the label **PS1**, press **SET** to display the value, modify it using **⏪** and **⏩**, then save it by pressing **SET** or **ⓘ**. If enabled, it will be required in order to access the User parameters.

**Password 'PA2'**: used to access **Installer** parameters. The password is enabled by default (**PS2=15**).

To modify it (**PS2≠15**): press and hold **SET** for longer than 5 seconds, scroll through the parameters using **⏪** and **⏩** until you see the label **PA2**, press **SET**, set the value to '15' using **⏪** and **⏩**, then confirm using **SET**. Scroll through the folders until you find the label **diS** and press **SET** to enter. Scroll through the parameters using **⏪** and **⏩** until you see the label **PS2**, press **SET** to display the value, modify it using **⏪** and **⏩**, then save it by pressing **SET** or **ⓘ**.

The visibility of **'PA2'** is as follows:

- 1) **PA1** and **PA2 ≠ 0**: Press and hold **SET** for longer than 5 seconds to display **PA1** and **PA2**. It will then be possible to decide whether to access the User parameters (**PA1**) or the Installer parameters (**PA2**).
- 2) **Otherwise**: The password **PA2** is amongst the level1 parameters. If enabled, it will be required when accessing the Installer parameters; to enter it, proceed as instructed for password **PA1**.

If the value entered is incorrect, the label **PA1/PA2** will be displayed again and the procedure will need to be repeated.

## MACHINE STATUS MENU

Access the Machine Status menu by pressing **SET** and releasing the key. If no alarms are active, the 'SP1' label appears. Use the keys **⏪** and **⏩** to scroll through all the folders in the menu:



- **AL:** alarms folder (**only visible if an alarm is active**);
- **SP1:** Setpoint 1 setting folder;
- **Pb1:** probe 1 - Pb1 folder;

**Setting the Setpoint:** To display the Setpoint value press the **SET** key when the 'SP1' label is displayed. The Setpoint value appears on the display. To change the Setpoint value, press the **⏪** and **⏩** keys within 15 seconds. Press **SET** to confirm the modification.

**Displaying probes:** When label Pb1 is present, press the **SET** key to view the value measured by the corresponding probe (**NOTE:** the value cannot be modified).

## PROGRAMMING MENU

To access the 'Programming' menu, press the **SET** key for more than 5 seconds. If specified, an access PASSWORD will be requested: **PA1** for User parameters and **PA2** for Installer parameters (see 'PASSWORD' paragraph).

**User Parameter:** When accessed, the display will show the first parameter (e.g. 'dF1'). Press **⏪** and **⏩** to scroll through all the parameters on the current level. Select the desired parameter by pressing **SET**. Press **⏪** and **⏩** to modify it and **SET** to save the changes.

**Installer Parameter:** When accessed, the display will show the first folder (e.g. 'rE1'). Press **⏪** and **⏩** to scroll through the folders on the current level. Select the desired folder using **SET**. Press **⏪** and **⏩** to scroll through the parameters in the current folder and select the parameter using **SET**. Press **⏪** and **⏩** to modify it and **SET** to save the changes.

**NOTE:** Switch the instrument off and on again each time the parameter configuration is changed

## DIAGNOSTICS

Alarms are always indicated by the alarm icon  and the buzzer.

To switch off the buzzer, press and release any key; the corresponding icon will continue to flash.

**N.B.:** If alarm exclusion times have been set, the alarm will not be signalled.

## ALARMS


Label	Description	Cause	Effects	Remedy
<b>E1</b>	Probe1 in error (ambient)	<ul style="list-style-type: none"> <li>measured values are outside operating range</li> <li>Probe inoperable/ short-circuited/open</li> </ul>	<ul style="list-style-type: none"> <li>Display label <b>E1</b></li> <li>Alarm icon permanently on</li> <li>Buzzer activation (if present)</li> <li>Disable max/min alarm controller</li> <li>Compressor operation based on parameters <b>On1</b> and <b>OF1</b></li> </ul>	<ul style="list-style-type: none"> <li>check probe type (<b>H00</b>)</li> <li>check probe wiring</li> <li>replace probe</li> </ul>
<b>AH1</b>	Alarm for HIGH value (Probe1)	value read by <b>Pb1</b> > <b>HA1</b> after time of <b>tAO</b> .	<ul style="list-style-type: none"> <li>Recording of label <b>AH1</b> in folder AL</li> <li>Alarm icon permanently on</li> <li>Buzzer activation (if present)</li> <li>No effect on regulation</li> </ul>	Wait until value read by Pb1 returns below <b>HA1</b> .
<b>AL1</b>	Alarm for LOW value (Probe1)	value read by <b>Pb1</b> < <b>LA1</b> after time of <b>tAO</b> .	<ul style="list-style-type: none"> <li>Recording of label <b>AL1</b> in folder AL</li> <li>Alarm icon permanently on</li> <li>Buzzer activation (if present)</li> <li>No effect on regulation</li> </ul>	Wait until value read by Pb1 returns above <b>LA1</b> .



## TELEVIS SYSTEM

The Televis remote control systems can be connected using the TTL serial port (TTL-RS485 **BusAdapter** 130 or 150 interface module must be used).

To configure the instrument to do this, you need to access the **Add** folder and use the **dEA** and **FAA** parameters.



**NOTE: CHECK THE AVAILABILITY OF MODELS COMPATIBLE WITH REMOTE SUPERVISION SYSTEMS.**


## DUTY CYCLE DIAGRAM

The device uses parameters On1 e OF1 set for Duty Cycle.

An error condition in probe1 (regulation) causes one of the following actions:

- Code '**E1**' is shown on the display
- The regulator is activated as indicated by parameters On1 and OF1 if set for Duty Cycle

On1	OF1	Regulator output
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	Duty Cycle



## TECHNICAL DATA (EN 60730-2-9)

Classification:	operation (not safety) device for incorporation
Mounting:	panel mounting with 71x29 mm (2.80x1.14 in.) drilling template
Type of action:	1.B
Pollution class:	2
Insulation material class:	IIIa
Overvoltage category:	II
Rated impulse voltage:	2500 V
Temperature:	{ UL models: Operating: 0...55 °C (32...131 °F) - Storage: -30...85 °C (-22...185 °F) Others: Operating: -5...55 °C (23...131 °F) - Storage: -30...85 °C (-22...185 °F)
Power supply:	{ <ul style="list-style-type: none"><li>• 12 Vac/dc (<math>\pm 10\%</math>)</li><li>• 24 Vac (<math>\pm 10\%</math>)</li><li>• 12-24 Vac/12-36 Vdc (<math>\pm 10\%</math>) (Dedicated power supply not grounded or earth connected)</li><li>• 115 Vac (<math>\pm 10\%</math>) 50/60 Hz</li><li>• 230 Vac (<math>\pm 10\%</math>) 50/60 Hz</li></ul>
Consumption:	{ <ul style="list-style-type: none"><li>• 1.5 VA max (model 12 Vac/dc)</li><li>• 4 VA max (models: 24 Vac, 12-24 Vac/12-36 Vdc, 115 Vac and 230 Vac)</li></ul>
Fire resistance category:	D
Software class:	A

**NOTE:** check the power supply specified on the instrument label.

## FURTHER INFORMATION

### Input/Output Characteristics

See 'Connections' section

### Mechanical Characteristics

Casing:	PC+ABS UL94 V-0 resin casing, polycarbonate window, thermoplastic resin keys
Dimensions:	front panel 78.6x37 mm (3.09x1.46 in.), depth 59 mm (2.32 in.) (without terminals)
Terminals:	screw/disconnectable terminals for cables with a diameter of 2.5 mm <sup>2</sup> (13 AWG)
Connectors:	TTL for connection of Unicard/Copy Card (maximum length 3 m / 118 in.)
Humidity:	Operating / Storage: 10...90 % RH (non-condensing)

### Regulations

Food Safety:	The device complies with standard EN13485 as follows: <ul style="list-style-type: none"><li>• suitable for storage</li><li>• application: air</li><li>• climate range A</li><li>• measurement class 1 in the range -25...15 °C (-13...59 °F) (*)</li></ul>
--------------	--

**(\* exclusively using Eliwell probes)**

**NOTE:** The technical specifications given in this document regarding measurement (range, accuracy, resolution, etc.) refer to the instrument and not to any accessories provided (for example: probes).

## PARAMETERS TABLE

PAR.	DESCRIPTION	MODEL	RANGE	VALUE	M.U.	LEVEL
SP1	Pb1 value control setpoint <b>SP1</b> . The <b>SEtpoint</b> is visible from the machine status menu and not from the programming menu.	NTC/PTC	LS1...HS1	0.0	°C/°F	/
		PT100-Tc		0.0	°C/°F	
		V/I		0	num	
REGULATOR 1 (folder 'rE1')						
HC1	This sets the controller 1 operating mode. <b>H</b> (0) = Hot; <b>C</b> (1) = Cold.	ALL	H/C	H	flag	Inst
OS1	Value to be added to <b>SP1</b> if reduced set enabled	NTC/PTC	-30.0...30.0	0.0	°C/°F	Inst
		PT100-Tc	-30.0...30.0	0.0	°C/°F	
		V/I	-30...30	0	num	
dF1	<b>Regulator 1</b> activation differential. The utility stops on reaching the <b>SP1</b> value (as indicated by control probe) and restarts at value equal to <b>T=SP1+dF1</b> relative to <b>HC1</b> .	NTC/PTC	0.0...30.0	1.0	°C/°F	User/Inst
		PT100-Tc	0.0...30.0	1.0	°C/°F	
		V/I	0...30	1	num	
HS1	Maximum value assignable to setpoint SP1.	NTC/PTC	LS1...HdL	140.0	°C/°F	User/Inst
		PT100-Tc		1350	°C/°F	
		V/I		199	num	
LS1	Minimum value assignable to setpoint SP1.	NTC/PTC	LdL...HS1	-50.0	°C/°F	User/Inst
		PT100-Tc		-199.9	°C/°F	
		V/I		-199	num	
HA1	Pb1 maximum value alarm on Regulator 1.	NTC/PTC	LA1...150.0	140.0	°C/°F	Inst
		PT100-Tc	LA1...1999	1350	°C/°F	
		V/I	LA1...150	150	num	
LA1	Pb1 minimum value alarm on Regulator 1.	NTC/PTC	-150.0...HA1	-50.0	°C/°F	Inst
		PT100-Tc	-328...HA1	-199.9	°C/°F	
		V/I	-150...HA1	-150	num	
dn1	Switch-on delay. The indicated time must elapse between the request for activation of the controller 1 relay and switch-on. <b>0</b> = not active.	ALL	0...250	0	s	Inst

PAR.	DESCRIPTION	MODEL	RANGE	VALUE	M.U.	LEVEL
<b>d01</b>	Delay time after switching off. The indicated time must elapse between deactivation of the controller 1 relay and the next switch-on. <b>0</b> = not active.	ALL	0...250	0	min	Inst
<b>di1</b>	Delay between switch-ons. The indicated time must elapse between two consecutive switch-ons of regulator 1. <b>0</b> = not active.	ALL	0...250	0	min	Inst
<b>dE1</b>	Switch-off delay. The indicated time must elapse between the request for deactivation of the controller 1 relay and switch-off. <b>0</b> = not active.	ALL	0...250	0	s	Inst
<b>On1</b>	Controller 1 switch-on time in the event of faulty probe. if <b>On1</b> =1 and <b>OF1</b> =0, the controller remains on; if <b>On1</b> =1 and <b>OF1</b> >0, the controller operates in Duty Cycle mode.	ALL	0...250	0	min	Inst
<b>OF1</b>	Controller 1 switch-off time in the event of faulty probe. if <b>OF1</b> =1 and <b>On1</b> =0, the controller remains off; if <b>OF1</b> =1 and <b>On1</b> >0, the controller operates in Duty Cycle mode.	ALL	0...250	1	min	Inst
ALARMS (folder 'AL')						
<b>AFd</b>	Alarm differential.	<b>NTC/PTC</b>	1.0...50.0	2.0	°C/°F	Inst
		<b>PT100-Tc</b>	1.0...50.0	2.0	°C/°F	
		<b>V/I</b>	1...50	2	num	
<b>tP</b>	Enable all keys to acknowledge an alarm. <b>n</b> (0) = no; <b>y</b> (1) = yes.	ALL	n/y	y	flag	Inst
COMMUNICATION (folder 'Add')						
<b>PtS</b>	Selection of communication protocol. <b>t</b> = Televis; <b>d</b> = Modbus.	ALL	t/d	t	flag	Inst
<b>dEA</b>	Index of the device within the family (valid values from 0 to 14).	ALL	0...14	0	num	Inst
<b>FAA</b>	Device family (valid values from 0 to 14).	ALL	0...14	0	num	Inst
<b>Adr</b>	Modbus protocol controller address.	ALL	1...255	1	num	Inst
<b>bAU</b>	Baudrate selection. <b>48</b> (0) = 4800; <b>96</b> (1) = 9600; <b>192</b> (2) = 19200; <b>384</b> (3) = 38400.	ALL	48/96/ 192/384	96	num	Inst
<b>Pty</b>	Modbus parity bit. <b>n</b> (0) = none; <b>E</b> (1) = even; <b>o</b> (2) = odd.	ALL	n/E/o	E	num	Inst
<b>StP</b>	Modbus stop bit. <b>1b</b> (0) = 1 bit; <b>2b</b> (1) = 2 bit.	ALL	1b/2b	1b	flag	Inst

PAR.	DESCRIPTION	MODEL	RANGE	VALUE	M.U.	LEVEL
DISPLAY (folder 'diS')						
<b>LOC</b>	LOCK. Setpoint edit lock. The parameter programming menu can still be accessed, and the settings changed, which means also that the status of this parameter can be changed so as to unlock the keypad. <b>n</b> (0) = no; <b>y</b> (1) = yes.	ALL	n/y	n	flag	User/Inst
<b>PS1</b>	Password 1. When enabled ( <b>PS1 ≠ 0</b> ) it is the password to the 'User' parameters (User).	ALL	0...250	0	num	User/Inst
<b>PS2</b>	Password 2. When enabled ( <b>PS2 ≠ 0</b> ) it is the password to the 'Installer' parameters (Inst).	ALL	0...250	15	num	Inst
<b>ndt</b>	Display values with decimal point. <b>n</b> (0) = no (without decimal point); <b>y</b> (1) = yes (with decimal point); <b>int</b> (2) = integer (V/I models only).	ALL	n/y/int	n	num	User/Inst
<b>CA1</b>	Calibration 1. Positive or negative value added to the value read by <b>Pb1</b> , according to the setting of parameter <b>CAI</b> .	<b>NTC/PTC</b>	-30.0...30.0	0.0	°C/°F	User/Inst
		<b>PT100-Tc</b>	-30.0...30.0	0.0	°C/°F	
		<b>V/I</b>	-30...30	0	num	
<b>CAI</b>	Intervention of the offset on display, temperature control or both. <b>0</b> = only the value shown is modified; <b>1</b> = sum with only the value used by the controllers and not for the display, which remains unchanged; <b>2</b> = sum with the displayed value, which is also used by the regulators.	ALL	0/1/2	2	num	Inst
<b>LdL</b>	Minimum value that can be displayed by the device.	<b>NTC/PTC</b>	-199.9...HdL	-50.0	°C/°F	Inst
		<b>PT100-Tc</b>	-328...HdL	-199.9	°C/°F	
		<b>V/I</b>	-199...HdL	-199	num	
<b>HdL</b>	Maximum value that can be displayed by the device.	<b>NTC/PTC</b>	LdL...199.9	140.0	°C/°F	Inst
		<b>PT100-Tc</b>	LdL...1350	1350	°C/°F	
		<b>V/I</b>	LdL...199	199	num	
<b>dro</b>	Select the unit of measurement of probe 1. • <b>NTC/PTC</b> and <b>PT100-Tc</b> : <b>C</b> (0) = °C, <b>F</b> (1) = °F • <b>V/I</b> : <b>n</b> (0) = no unit of measure selected, <b>t</b> (1) = temperature, <b>P</b> (2) = pressure, <b>H</b> (3) = humidity	<b>NTC/PTC</b>	C/F	C	flag	Inst
		<b>PT100-Tc</b>	C/F	C	flag	
		<b>V/I</b>	n/t/P/H	n	num	

PAR.	DESCRIPTION	MODEL	RANGE	VALUE	M.U.	LEVEL
CONFIGURATION (folder 'CnF') ➡ If one or more parameters are changed, the controller MUST be switched off and switched on again.						
H00	Probe type selection. <ul style="list-style-type: none"> <li>• <b>NTC/PTC</b>: <b>Ptc</b> (0) = PTC, <b>ntc</b> (1) = NTC</li> <li>• <b>PT100-Tc</b>: <b>Jtc</b> (0) = TcJ, <b>Htc</b> (1) = Tck, <b>Pt1</b> (2) = PT100.</li> <li>• <b>V/I</b>: <b>420</b> (0) = 4...20mA, <b>020</b> (1) = 0...20mA, <b>t10</b> (2) = 0...10V, <b>t05</b> (3) = 0...5V, <b>t01</b> (4) = 0...1V.</li> </ul>	<b>NTC/PTC</b>	Ptc/ntC	ntc	flag	User/Inst
		<b>PT100-Tc</b>	Jtc/Htc/Pt1	Jtc	num	
		<b>V/I</b>	420/020 t10/t05/t01	420	num	
H02	Press the ESC, UP and DOWN keys (if configured for a second function) for the time <b>H02</b> to activate the function itself.	ALL	0...15	5	s	Inst
H03	Lower input current/voltage limit. (only present on model V/I)	<b>NTC/PTC</b>				User/Inst
		<b>PT100-Tc</b>				
		<b>V/I</b>	-1999...1999	0	num	
H04	Upper current/voltage limit for input. (only present on model V/I)	<b>NTC/PTC</b>				User/Inst
		<b>PT100-Tc</b>				
		<b>V/I</b>	-1999...1999	1000	num	
H05	Window filter: -2 = very fast; -1 = fast; 0 = normal; 1 = slow; 2 = very slow.	ALL	-2/-1/0/1/2	0	num	Inst
H08	Stand-by operating mode. 0 = only display switches off; 1 = display on and controllers locked; 2 = display off and controllers locked.	ALL	0/1/2	2	num	Inst
H10	Delay for output activation after Power On. If <b>H10</b> = 0 the delay is NOT active; if <b>H10</b> ≠ 0 the output will not be activated before this time has expired.	ALL	0...250	0	min	Inst
H31	Configuration of <b>UP</b> key. 0 = disabled; 1 = not used; 2 = Offset setpoint; 3 = OUT1 stopped; 4 = not used; 5 = not used; 6 = Stand-by; 7 = not used.	ALL	0...7	0	num	Inst
H32	Configuration of <b>DOWN</b> key. Same as <b>H31</b> .	ALL	0...7	0	num	Inst
H33	Configuration of <b>ESC</b> key. Same as <b>H31</b> .	ALL	0...7	6	num	Inst

PAR.	DESCRIPTION	MODEL	RANGE	VALUE	M.U.	LEVEL
rEL	firmware version. Device software release: <b>read-only parameter.</b>	ALL	/	/	/	User/Inst
tAb	Parameters table. Reserved: <b>read-only parameter.</b>	ALL	/	/	/	User
COPY CARD (folder 'FPr')						
UL	Upload. Transfer of programming parameters from instrument to Copy Card.	ALL	/	/	/	Inst
dL	Download. Transfer of programming parameters from Copy Card to instrument.	ALL	/	/	/	Inst
Fr	Format. Cancels all data entered in the Copy Card. <b>Note:</b> If parameter Fr (Copy Card formatting) is used, the data entered in the card will be permanently lost. This operation cannot be reversed.	ALL	/	/	/	Inst
FUNCTIONS (folder 'FnC')						
Function	Function label ACTIVE	Function label NOT ACTIVE	D.I.	KEY	Alarm signaling	
Reduced setpoint	OSP	SP	2	2	ON Icon	
Stand-by	On	OF	6	6	ON Icon	
Alarm acknowledgement	tAL	tAL	7	7	ON Icon	
<b>NOTES:</b> - to modify the status of a given function, press the ' <b>set</b> ' key - If the instrument is switched off, the function labels will return to the default status						

## LIABILITY AND RESIDUAL RISKS

ELIWELL CONTROLS SRL declines any liability for damage due to:

- installation/uses different from those specified and, in particular, not complying with the safety regulations and/or instructions given in this document;
- use on panels that do not provide adequate protection against electric shocks, water or dust when assembled;
- use on panels allowing access to dangerous parts without the use of tools;
- tampering with and/or modifying the product;
- installation/use on panels not complying with current standards and regulations.



## DISCLAIMER

This document is the exclusive property of ELIWELL CONTROLS SRL and may not be reproduced or circulated unless expressly authorised by ELIWELL CONTROLS SRL itself.

Every care has been taken in preparing this document; nevertheless ELIWELL CONTROLS SRL cannot accept liability for any damage resulting from its use. The same applies to any person or company involved in preparing and editing this document. ELIWELL CONTROLS SRL reserves the right to make aesthetic or functional changes at any time without notice.

## CONDITIONS OF USE

### Permitted use

For safety reasons, the instrument must be installed and used according to the instructions supplied and, in particular, parts under dangerous voltages must not be accessible in normal conditions.

The device must be adequately protected from water and dust with regard to its application, and must only be accessible using tools (except for the front panel). The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested for safety aspects in accordance with the harmonised European reference standards.

### Improper use

Any use other than that expressly permitted is prohibited. The relay contacts provided are of a functional type and subject to failure: any protection devices required by product standards, or suggested by common sense for obvious safety requirements, must be installed externally to the instrument.

## DISPOSAL



The appliance (or the product) must be disposed of separately in compliance with the local standards in force on waste disposal.

## **Eliwell Controls s.r.l.**

Via dell'Industria, 15 - Z.I. Paludi  
32010 Pieve d'Alpago (BL) ITALY

T: +39 0437 986 111

F: +39 0437 989 066

**www.eliwell.com**

## **Technical Customer Support:**

T: +39 0437 986 300

E: Techsuppeliwell@schneider-electric.com

## **Sales:**

T: +39 0437 986 100 (Italy)

T: +39 0437 986 200 (other countries)

E: saleseliwell@schneider-electric.com



ISO 9001



cod. 9IS44315-1 • ICPlus 902 • EN • rel. 07/16

© **Eliwell Controls s.r.l. 2016 • Tutti i diritti riservati.**