



All condensers must be tested for leaks and then charged with nitrogen.
 Over pressure in the condenser should be kept at least 60PSI.
 The inlet and outlet for soft temper copper tube.

15hp