DV-405 WIRELESS MICRON GAUGE






JB INDUSTRIES

WWW.JBIND.COM 800.323.0811 SALES@JBIND.COM

HOW TO TURN ON/OFF DV-40S WIRELESS MICRON GAUGE

To turn power on/off, press blue power button on bottom of DV-40S once



To charge unit, plug micro-USB into female micro-USB port on bottom of DV-40S

CONNECTING A SMART DEVICE TO DV-40S

REQUIREMENT:

Apple iPhone 4s or higher and iPad 3 or higher OR

Android 4.3 or higher

INSTALL THE FREE JB DV-40S APP

Available in the Apple App Store and Google Play for Android






BEGIN WITH DV-40S OFF AND AN UNPAIRED TABLET OR PHONE

- 1 Turn on the smart device (tablet or phone)
- 2 Turn on Bluetooth in your smart device settings



3 Turn on the DV-40S on by pressing the blue power button



4 Touch the "JB" icon at the upper left of the app



5 From the expanding menu, select "Scan" to search for compatible devices

CONNECTING A SMART DEVICE TO DV-40S (CONTINUED)

6 Select your vacuum gauge from the list of detected devices



IF THE DV-40S DOES NOT APPEAR IN THE LIST OF DETECTED DEVICES:

Make sure it is unpaired from any other, previously used, smart device.

Turn off both the DV-40s and smart device, and start over from step one.

7 Verify the connection by looking at the signal strength indicator on the DV-40S



8 The DV-40S is now paired to your smart device and is ready for use

IF THE DV-40S DOES NOT CONNECT AFTER SELECTING IT:

Make sure it is unpaired from any other, previously used, smart device. Turn off both the DV-40s and smart device, and start over from step one.



FOR MORE INFORMATION ON THE JB DV-40S WIRELESS MICRON GAUGE & FULL MANUAL VISIT US AT WWW.JBIND.COM

CONNECT WITH US











INDUSTRIES

WWW.JBIND.COM 800.323.0811 SALES@JBIND.COM